

MERCURY

KIEKHAEFER CORP.

Fond du Lac, Wisc. 54935

MARK 5, 6 AND 6A

Year Produced	6 hp
1955	Mark 5
1956	Mark 6
1957	Mark 6
1958	Mark 6
1959	Mark 6A

CONDENSED SERVICE DATA

TUNE-UP

Hp @ rpm	6 @ 4500
Bore — Inches	1 3/4
Stroke — Inches	1 1/2
Number of cylinders	2
Displacement — Cu. In.	7.2
*5 @ 4200 for Mark 5	

Spark Plug

Champion	J7J
AC	M45
Electrode gap	0.025

Magneto

Make	Scintilla or Phelon
Point gap	0.018

Carburetor

Make	Tillotson
Model	AJ-30B or AJ-46A
Fuel — Oil Ratio	20:1

SIZES—CLEARANCES

Piston Rings
 End Gap
 Side Clearance
 Piston Skirt Clearance

Crankshaft Bearing Journal Diameter
 Upper main bearing
 Center main bearing
 Lower main bearing
 Crankpin

Crankshaft Bearings—

Upper main bearings	Ball & Roller
Center main bearing	Bushing
Lower main bearing	Roller
Crankpin	Loose Rollers
No. of rollers (each rod)	23
Crankshaft End Play	Zero
Piston Pin Bearing in rod	Loose Rollers
No. of rollers (each rod)	17

Publication
 Not Authorized
 by Manufacturer

TIGHTENING TORQUES

(All Values In Inch—Pounds)

Connecting Rod	80
Flywheel Nut	480
Spark Plug	240
Propeller Clutch	170-240

LUBRICATION

The power head is lubricated by oil mixed with the fuel. If "Formula 2 Quicksilver" two-cycle engine oil is used, one 12 ounce can should be mixed with each 2 gallons of gasoline. If "Quicksilver" oil is not available, a good grade, non-detergent, SAE 30 or SAE 40 motor oil may be substituted by increasing oil ratio to 1/2-pint oil with each gallon of gasoline (1:16 ratio).

The lower unit gears and bearings are lubricated by oil contained in the gear case. Only "EXTRA-DUTY Quicksilver Outboard Gear Lubricant" should be used. Gearcase is filled through the forward plug hole on starboard side of case, with motor in an upright position. The vent plug (located aft of fill plug) should be removed when filling. Lubricant should be maintained at level of vent plug.

FUEL SYSTEM

CARBURETOR. Tillotson AJ series, float type carburetors are used on all models. Refer to Fig. M1-1. Initial setting for the high speed (main) mixture needle (14) is 1 1/2 turns open. Initial setting for idle mixture needle (13) is 1 turn open. To adjust, run motor until it reaches normal operating temperature, then shift to forward gear and move speed control to fast. Slowly turn high speed needle (14) clockwise until motor falters or slows down because mixture is too lean. Then, back needle out approximately 1/2 turn until mixture is correct. After setting high speed needle (14), slow engine speed and adjust idle mixture with needle (13). Turning needle (13) clockwise, leans idle mixture. Recheck high speed adjustment after changing idle speed mixture.

To adjust the fuel level, remove bowl cover (1) and refer to Fig. M1-2. Invert the cover and measure distance (A) between primary lever (6) and gasket surface of bowl cover with inlet valve (3) closed. This distance should be 3/32 inch; if it is not, bend the curved tang on secondary lever (4) until correct measurement is obtained. After ad-

Mercury Mark 5, 6 & 6A

justing float height, bend the vertical tang on primary lever (6) to allow a maximum clearance of 0.040 between secondary lever (4) and inlet needle (3).

SPEED CONTROL LINKAGE. The speed control moves the magneto stator plate to advance or retard ignition timing. The carburetor throttle valve is synchronized to open as the timing is advanced. Before attempting to synchronize throttle opening to ignition advance, the idle fuel mixture must be correctly set and idle speed should be approximately 500 rpm. Run motor until it reaches operating temperature, engage forward gear, then move speed control handle until engine is operating approximately 1000 rpm. NOTE: On Mark 5, speed control handle will be about center of motor. With controls set as outlined, the control cam (1—Fig. M1-3) attached to magneto stator plate should just contact the throttle follower lever (2). Adjust by loosening the cam attaching screws and move cam on stator plate until it just contacts follower lever (2).




Fig. M1-1—Exploded view of Tillotson carburetor of the type used on all models.

- | | |
|------------------------|-----------------------------|
| 1. Bowl cover | 12. Body |
| 2. Filter | 13. Idle needle |
| 3. Inlet needle & seat | 14. High speed needle |
| 4. Secondary lever | 15. Gland nut |
| 5. Shaft | 16. Packing |
| 6. Primary lever | 17. Plug |
| 7. Shaft | 18. Throttle valve |
| 8. Float spring | 19. Throttle shaft |
| 9. Float | 20. Throttle stop lever |
| 10. Idle tube | 21. Throttle follower lever |
| 11. Throttle spring | |




Fig. M1-2—Schematic view of float mechanism. Refer to text for method of adjustment.

108

REED VALVES. The inlet reed valves are located on the crankshaft center main bearing assembly as shown in Fig. M1-4. Crankshaft must be removed before reed valves can be serviced.

Reed petals (RP) should be perfectly flat and have no more than 0.007 clearance between free end of reed petal and seating surface of center main bearing. The reed stop (RS) must be carefully adjusted to provide 7/64-inch clearance between end of stop and seating surface on bearing housing as shown at (A). Seating surface of bearing must be smooth and flat, and may be re-finished on a lapping plate after removing reed valves and dowels. Do not attempt to bend or straighten a reed petal to modify performance, and never install a bent petal.




Fig. M1-3—Schematic view of speed control linkage. Refer to text for details of adjustment.

1. Throttle cam
2. Follower lever




Fig. M1-4—Center main bearing showing inlet reed valves. Adjustment (A) of reed stop (RS) is 7/64 inch.

- | | |
|----------------|----------------|
| A. Adjustment | RP. Reed petal |
| IP. Inlet port | RS. Reed stop |

OLD OUTBOARD MOTOR

Lubricate the reed valve units with "Quick-silver" Multipurpose lubricant or a light distributor cam grease when reassembling.

FUEL PUMP. A diaphragm type fuel pump is used, which is operated by pressure and vacuum pulsations in the lower crankcase as shown in Fig. M1-5. Vacuum in the crankcase draws the diaphragm down, pulling fuel past the inlet check valve as shown in view "A." Crankcase pressure forces the diaphragm out and the trapped fuel enters the carburetor line past the outlet check valve as shown in view "B."

All defective or questionable parts should be renewed. Check valves must both be pressed out at the same time, working from the OUTLET side of fuel passage. Press valves in from inlet side to the depths shown in Fig. M1-6.

IGNITION

Breaker point gap should be set at approximately 0.018 on highest lobe of cam. The two sets of points should be set to open at exactly 180 degree intervals. The points may be synchronized by using the Mercury Synchronizing Tool set, part number 91-28619A1 shown in Fig. M1-7 (or equivalent).




Fig. M1-6—When renewing the fuel pump check valves, press both valves in from inlet side to the distances shown.




Fig. M1-5—Schematic view of diaphragm type fuel pump showing method of operation. Vacuum - Pressure line attaches to lower crankcase. When powerhead piston moves upward in cylinder, vacuum in crankcase draws diaphragm out and fuel in as shown in view "A." Crankcase pressure resulting from power stroke forces diaphragm in and fuel out as shown in view "B."

plus a timing test light. To adjust the timing, remove the flywheel and install the degree plate and pointer (P). Set the contact points for top cylinder at 0.018. Remove the spark plugs and install the test light by attaching one clip to insulated point connection and the other clip to a suitable ground. Turn the crankshaft clockwise slowly until the points just open as indicated by the test light bulb going out. Turn the degree plate until the 0° timing mark is aligned with the pointer as shown. Attach the test light to the other set of points and turn the crankshaft

until timing pointer is aligned with the 180° timing mark on degree plate; then adjust the second set of points to barely open. Recheck both sets of points with the degree plate and timing light. If the synchronizing tools are not available, adjust point gap to exactly 0.018 for both sets of points.

COOLING SYSTEM

WATER PUMP. The rubber impeller type water pump is housed in the lower drive shaft housing. Impeller is mounted on and driven by the lower unit drive shaft.

When cooling system problems are encountered, first check the water inlet for plugging or partial stoppage, then if not corrected, remove and disassemble the lower unit as outlined in the LOWER UNIT section and examine the water pump, water tubes and seals. The water inlet is located on the sides of the lower unit gearcase, the water passing up through a housing which surrounds the propeller shaft.

POWER HEAD

R&R AND DISASSEMBLE. To remove the power head assembly, first remove the top cowl, then disconnect and remove the shift cable. Remove the slotted special screw in front top of lower unit driveshaft housing, loosen the clamping bolt at top rear of driveshaft housing, then withdraw the lower unit assembly downward out of swivel bracket and power head assembly. Loosen the clamping screw in co-pilot locking ring (10—Fig. M1-8) and withdraw the power head assembly upward out of swivel bracket and lower cowl.

The powerhead stand, Mercury part number 91-24282, or equivalent is required to disassemble the removed power head. Place

the stand in a vise and set the powerhead on the stand; then remove the flywheel, magneto, carburetor and inlet manifold. Remove the housing cap (1) and dished thrust washer (3) from upper bearing housing, remove flywheel key, then unscrew and remove the upper bearing retaining nut (2).

NOTE: Nut is secured with LEFT HAND thread.

Remove the screws retaining bearing housing (5), then remove housing using a puller with legs which will screw into threaded holes in housing.

Remove the spark plugs, then unbolt and remove the cylinder assembly from the crankcase, crankshaft and pistons assembly. Cylinder block cover (6—Fig. M1-9) and inlet port cover (2) should be removed for inspection and cleaning of the block.

Remove the screws retaining water inlet cap (13—Fig. M1-8) from crankcase pivot tube using Mercury tool number 91-24279, or a No. 1 Phillips screwdriver socket and extension. Remove the water inlet cap (13).

Hold the connecting rod cap with the formed cap holder (Tool Number 91-24281), remove the retaining screws, then remove the connecting rod and piston assemblies. Keep the assemblies together and make sure they are properly marked for reinsertion in the same cylinder. There are 23 loose needle




Fig. M1-7—Synchronizing tool installed for adjusting the magneto points. Refer to text for details.

DP, Degree plate P, Pointer




Fig. M1-8—Exploded view of the one-piece crankcase and associated parts.

- 1. Housing cap
- 2. Bearing nut
- 3. Thrust washer
- 4. Ball bearing
- 5. Housing
- 6. Roller bearing
- 7. Gasket
- 8. Crankcase
- 9. Roller bearing
- 10. Co-pilot ring
- 11. Gasket
- 12. Oil seal
- 13. Water inlet cap
- 14. Rushing




Fig. M1-9—Exploded view of power head cylinder and component parts.

- 1. Gasket
- 2. Transfer port cover
- 3. Gasket
- 4. Cylinder
- 5. Gasket
- 6. Cylinder cover
- 7. Pivot lever
- 8. Link lever
- 9. Clutch bracket




Fig. M1-10—Schematic view of crankcase showing method of removing and installing crankshaft. Refer to text.

- 1. Housing cap
- 2. Bearing nut
- 3. Thrust washer
- 4. Ball bearing
- 5. Bearing housing
- 6. Roller bearing
- J, Jacks
- CM, Center main bearing
- LS, Locking screw

rollers in each connecting rod crankpin bearing. Make sure all bearings are removed from crankcase and kept with the connecting rod from which they were removed.

Remove the center main bearing locking screw from side of crankcase and scribe a line across center main bearing and center bridge of crankcase to aid in alignment of bearing when reinstalling. Refer to Fig. M1-10. Place spacers or jacks (J) between counterweights of crankshaft to prevent springing or breakage of shaft. Jacks may be fashioned of brass, hardwood blocks, or a short bolt and nut may be used. Use the Mercury powerhead stand as an arbor, and press the crankshaft and center main bearing out the top of the crankcase assembly. Inspect and overhaul the power head components as outlined in the appropriate following paragraphs.

ASSEMBLY. When assembling, the crankcase and inlet manifold must be completely sealed against both vacuum and pressure. Exhaust manifold and water passages must be sealed against water leakage. Whenever powerhead is disassembled, it is recommended that all gasket surfaces be carefully checked for nicks and burrs which might interfere with a tight seal.

Coat gasket surfaces lightly and evenly with a non-hardening type gasket cement. Lubricate all friction surfaces with new engine oil before assembly. A light, non-fibrous grease should be used to retain loose needle bearings.

Make sure scribe lines on center main bearing and crankcase are aligned and press the crankshaft assembly in place, using the jacks (J—Fig. M1-10), until the threaded lockscrew hole in center main bearing is aligned with the hole in crankcase. Install and tighten the locking screw (LS). Reinstall upper bearing housing (5), bearing (4) and the crankshaft nut (2). Tighten nut until the clearance between center main bearing and crankshaft is equal at top and bottom; then align one castellation of nut with the crankshaft key slot, and install key with lower end locking the nut in position as shown.

Install connecting rods, using the formed holding tool (91-24281), making sure that alignment marks on rod and cap are matched. Piston must be installed with




Fig. M1-11—Exploded view of crankshaft and center main bearing assembly.

- | | |
|------------------------|--------------------|
| 1. Crankshaft | 4. Reed petal |
| 2. Center main bearing | 5. Reed stop |
| 3. Locking screw | 6. Retaining screw |

sharp vertical side of deflector toward intake and long sloping side toward exhaust port in cylinders. Tighten the connecting rod screws to a torque of 80 inch pounds. Install the cylinder assembly using a ring compressor, install the retaining screws loosely, then rotate the crankshaft to align the block before tightening the retaining screws.

PISTONS, PINS, RINGS & CYLINDERS. Before detaching connecting rods from crankshaft, make sure that rod and cap are properly identified for correct assembly to each other and in the correct cylinder.

Each piston is fitted with three rings which are interchangeable in the ring grooves and are pinned in place.

Piston pin is pressed in piston bosses and secured with retaining rings. Piston end of connecting rod is fitted with 17 loose needle bearings which use the connecting rod bore and the piston pin as bearing races. Install bearing washers and needle bearings in upper end of connecting rod, then install and center the piston pin using Mercury tool (C-91-24144A2). Piston must be installed so that sharp vertical side of deflector will be toward intake and long sloping side of piston toward exhaust side of cylinder when powerhead is assembled. Thoroughly lubricate all friction surfaces during assembly.




Fig. M1-12—Exploded view of recoil starter showing component parts.

- | | |
|--------------------|--------------------|
| 1. Recoil spring | 9. Collar |
| 2. Sheave shaft | 10. Pawl |
| 3. Sheave | 11. Cable |
| 4. Retaining screw | 12. Handle |
| 5. Shim | 13. Friction plate |
| 6. Washer | 14. Ratchet |
| 7. Pawl retainer | 15. Spacer |
| 8. Wave washer | 16. Washer |

CONNECTING RODS, BEARINGS AND CRANKSHAFT. Upper end of crankshaft is carried by a ball bearing which also controls end thrust, plus a caged needle bearing. The unbushed center main bearing (2—Fig. M1-11) contains the inlet reed valves. Lower main bearing is a caged needle roller type which should be pressed into crankcase until upper edge is $\frac{1}{16}$ -inch below bottom of crankcase.

Connecting rod rides in 17 loose needle rollers at piston end and 23 loose needle rollers at crankpin end of rod. Check rod for alignment, using Mercury alignment tool (C-91-28441A2), or by placing rod on a surface plate and checking with a light.

If bearing surface of rod and cap is rough, scored, worn, or shows evidence of overheating, renew the connecting rod. Inspect crankpin and main bearing journals. If scored, out-of-round, or worn, renew the crankshaft. Check crankshaft for straightness using a dial indicator and Vee-blocks.

Inspect and adjust the reed valves as outlined in REED VALVE paragraph, and reassemble as outlined in ASSEMBLY paragraph.

MANUAL STARTER

Refer to Fig. M1-12. To install a new starter cord (cable) or spring, remove and invert the top cowl assembly. Pry the cable bushing insert from handle with a screwdriver, slip handle (12) back on starter cable and cut the retaining knot. Release the cable and allow the recoil spring to unwind. Unbolt and remove the friction plate (14) and the starter pawls (10); then remove the sheave retaining screw (4). Slowly pull the sheave (3) down, working behind sheave to make sure the recoil spring (1) remains in recess in housing. Spring can be removed from recess after sheave is removed. NOTE: Wear cotton gloves or protect the hands with a cloth, then grasp and remove the spring, allowing it to unwind slowly after removal.

Unwind the cable (11) from sheave and remove the two anchor screws to release the cable. Install new cable by inserting anchor end in cable slot and twisting $\frac{1}{2}$ -turn to lock in place. Wind cable 1 full turn around sheave, then fasten with the 2 locking screws and thread guards. Continue to wind cable in sheave, leaving enough cable free of sheave to insert through cover opening. Lubricate the recoil spring (1) lightly with "Quicksilver" Multipurpose Lubricant and engage inner loop of spring on sheave anchor pin. Position sheave in cover and secure with the locking screw (4); then wind the recoil spring 3 full turns, pull cable through cover and tie a loose knot on outside of housing, leaving sufficient free end to install the handle (12). Complete the assembly by reversing the disassembly procedure.

To renew the sheave (3), shaft (2) or pawl retainer (7), first remove the sheave as previously outlined, grind off the peened end of shaft (2) and drive the shaft out of collar (9) with a punch. Use Fig. M1-12 as a guide for disassembly and reassembly, and peen the collar (9) to shaft (2), making sure sheave is free to turn.

LOWER UNIT

PROPELLER AND DRIVE CLUTCH. Protection for the motor is provided by the multiple disc clutch located in the propeller hub. To check the clutch torque, first remove the complete lower unit assembly as outlined in the following R&R AND OVERHAUL paragraph, then separate the gearcase housing from drive shaft lower housing. Clamp the neutral clutch drum (upper end of lower drive shaft) in a soft jawed vise and use the special Torque Adapter Tool, 91-2406 (See Fig. M1-14) and a torque wrench to check the torque. Propeller should turn on shaft at a torque of 170-240 inch-pounds.

If clutch tension must be increased, straighten the tabs on the propeller nut locking washer (26—Fig. M1-16) and tighten the propeller nut until the proper torque is applied. If propeller nut bottoms on shaft,




Fig. M1-13—Lower unit gearcase with propeller removed showing the multiple disc drive clutch. Refer to text for details.
CD. Clutch discs




Fig. M1-14—Checking and adjusting the drive clutch torque requires the use of the special pronged tool. Refer to text.



Fig. M1-15—Partially disassembled view of the three-piece lower unit showing location of the two stud nuts (1 & 3) and the retaining screw (2) which hold lower unit together. Refer to text for disassembly procedure.

remove the nut and place a shim behind the compression spring (27). Shims are available in thicknesses of 0.015 and 0.031. An inoperative clutch can be cleaned or the parts renewed by removing the propeller after tension nut is off. Clutch contains 7 externally splined friction discs (23) and 7 internally splined discs (24) which must be alternated on shaft.

R&R AND OVERHAUL. To remove the complete lower unit, first remove the top cowl and disconnect and remove the shift cable. Remove the slotted special screw in front top of lower unit driveshaft housing, loosen the clamping screw at top rear of housing; then pull the complete lower unit downward out of power head.

Clamp the gearcase housing in a vise (above the propeller shaft) using formed wood blocks to protect the housing. Remove the stud nuts (1 & 3—Fig. M1-15) and the Phillips head screw (2).

Hold the upper driveshaft, if necessary, and turn the propeller counter-clockwise while pulling the housings apart, to allow the neutral clutch to separate.

To disassemble the gearcase, remove the propeller and drive clutch as outlined previously, then remove the gearcase cover (21—Fig. M1-16) using Mercury tool 91-24267 or a suitable spanner wrench. NOTE: Gearcase cover is secured with left-hand thread.

Withdraw the propeller shaft assembly and remove the shims (10) from gearcase housing, if used. Bend down the tab washer retaining the drive pinion cap screw (8) and remove the cap screw and pinion (7). Clamp upper end of shaft (6) in a soft jawed vise and tap the gearcase housing from shaft assembly using a soft hammer. Remove and save the shims (5).

To disassemble the propeller shaft assembly, remove snap ring (14) and shims (13); then press bearing (12) from gear. Gear can be pressed from shaft after removing the loose locating pin (15). When reassembling, adjust gear backlash to 0.003-0.005 by means of shims (10). Adjust propeller shaft end play to a minimum by means of shims (13).

When reassembling, hold the upper drive shaft if necessary, and turn the propeller shaft counter-clockwise while moving the housings together, to allow the neutral spring to feed into place.




Fig. M1-16 — Exploded view of lower unit gearcase and associated parts.

- | | | |
|----------------------|---------------------|--------------------------|
| 1. "O" ring | 11. Driven gear | 20. Water intake housing |
| 2. Spacer | 12. Ball bearing | 21. Gearcase cover |
| 3. Clutch drum | 13. Shim | 22. Thrust plate |
| 4. Ball bearing | 14. Snap ring | 23. Clutch disc |
| 5. Shim | 15. Locating pin | 24. Clutch disc |
| 6. Lower drive shaft | 16. Propeller shaft | 25. Propeller |
| 7. Drive pinion | 17. Sealing washer | 26. Tab washer |
| 8. Screw | 18. Sealing washer | 27. Clutch spring |
| 9. Gearcase | 19. Oil seal | 28. Propeller nut |
| 10. Shim | | |

Copyright of *Old Outboard Motor Service Manual*, 1st Edition is the property of Penton Media, Inc. ("Clymer") and its content may not be copied or emailed to multiple sites or posted to a listserv without the copyright holder's express written permission. However, users may print, download, or email articles for individual use.