

PHOTO AND PART NUMBERS FOR SHROUD GROUP

Photo No.	Part No.	Name of Part	Photo No.	Part No.	Name of Part
1	303984	Hinge Pin	24	303528	Cover
2	376420	Shroud and Transfer Assembly Complete	25	303529	Grommet
3	203290	Bumper	26	304018	Seal
4	303480	Lockwasher	27	304027	Screw
5	303564	Bumper	28	304022	Screw
6	303958	Bumper	29	304021	Clamp - Outer
7	303522	Pin	30	304020	Clamp - Inner
8	376129	Clamp and Lever Assembly	31	300258	Screw
9	303519	Spring	32	304016	Motor Cover - Lower Rear
10	303590	Cotter Pin	33	303714	Screw
11	303985	Boss	34	304028	Motor Cover - Lower Front
12	19-189	Screw	35	303820	Transfer - "Johnson"
13	302761	Screw	36	303821	Transfer - Start and Oil
14	303521	Adjusting Lever - High Speed	37	303822	Transfer - Sea- Horse 25 - Front
15	303796	Grommet	38	303823	Transfer - "25" Sea-Horse
16	303718	Choke Knob	39	304075	Transfer - Electric Starting
17	303847	Adjusting Lever - Slow Speed	40	303824	Transfer - Gearshift
18	376332	Control Panel and Transfer Assembly	41	304017	Grommet
19	303983	Grommet	42	303959	Sleeve
20	41-163	Cotter Pin	43	303960	Washer
21	303535	Grommet	44	39-176	Screw
22	202065	Washer	45	43-302	Washer
23	303518	Spring			

Order All Parts from Nearest Service Station or Dealer